

FIG 1




FIG 2

2/4




FIG 3




FIG 4

POWER-UP OF ANY
SECONDARY NODE
402

CONVEY POWER-UP TO
SERVICE PROCESSOR OF
BOOT NODE
404

STARTUP SINGLE-PARTITION
SYSTEM BY SERVICE
PROCESSOR OF BOOT NODE
406

400

FIG 5

POWER-DOWN
OF ANY SECONDARY
NODE
502

CONVEY POWER-DOWN
TO SERVICE PROCESSOR
OF BOOT NODE
504

SHUT DOWN SINGLE-PARTITION
SYSTEM BY SERVICE PROCESSOR
OF BOOT NODE
506

500

FIG 6

RESET
OF ANY SECONDARY
NODE
602

CONVEY RESET TO
SERVICE PROCESSOR OF
BOOT NODE
604

RESET SINGLE-PARTITION
SYSTEM BY SERVICE PROCESSOR
OF BOOT NODE
606

600